CEZARES ANIMA R1

Sliding door

Installation manual-



General Information

Please inspect the product immediately upon receipt for transit damage, missing packs/parts or manufacturing fault. Damage reported later cannot be accepted. Please handle the product with care av oiding knock s and shock loading to all sides and e dges of the glass.

Note:Safety glass can not be re-wo rked.

Installation

Please read these instruct ions carefully before start of insta llation.

The wall post has up to 20mm of adjustment for out o f true wall situations.

Ensure that the shower tray is fitted level and that after assembly of enclosure there is a full and continuous bead of sealant between the top of the shower tray and the title joint.

Special care should be taken when dril ling walls to avoid hidden pipes or electrical c ables.

Note:T his product is heavy and will requeire two people to install.

Please remove protective film from aluminium profiles before installation.

■ Shower Tray In stallation

The shower tray must be sited against a structural wall.

Water proof walling or tiling should be fitted so that it sits on the top of the trayrim.

Afterc are Instructions

After use, your shower should be cleaned with soap and water. This is particularly important in hard water districts where insoluble lime salts may be deposited and allowed to build up. Cleaners of a gritty or abrasive nature should not be used. Care should be taken to avoid contact with strong chemical s such as organic solvents and str ippers.

Glass cleaners can be used but with caution, if in doubt contact the supplier of the cleaner in question.

Please keep these instructions for aftercare and customer service details.

Tools required ф3mm Φ 8mm σ This product is heavy and will require two people to install.









